

**VLF - HF - RECEIVER  
EK 070**

 Repair Manual  
 Part 6: Repair

- 6.93/6.94 -




Fig. 6.8 Front View of EK 070 (Control Diagram, LCD Version)